



CATALOG#	"A" DIM	"A" DIM
88WB	5	5
812WB	5	5
1010WB	7	7
1012WB	7	7
1212WB	9	9
1216WB	9	9
1218WB	9	9
1224WB	9	9
1518WB	12	12
1524WB	12	12
1530WB	12	12
1616WB	13	13
1810WB	15	15
1818WB	15	15
1824WB	15	15
1830WB	15	15
2018WB	17	17
2024WB	17	17
2424WB	21	21
2430WB	21	21
2434WB	21	21
2436WB	21	21
2442WB	21	21
2448WB	21	21
2472WB	21	21
3030WB	27	27
2731WB	27	27
3036WB	27	27
3042WB	27	27
3048WB	27	27
3060WB	27	27
3636WB	33	33
3648WB	33	33
3660WB	33	33
4848WB	45	45
4880WB	45	45
4896WB	48	48
3072WB	30	30
6060WB	60	60



MILBANK
ENERGY AT WORK

Version:

1

**All dimensions are +/- 1/16".
Drawing views are not to scale.**

Please consult serving utility for their requirements prior to ordering or installing, as specifications and approvals vary by utility, and may require local electrical inspector approval. All installations must be installed by a licensed electrician and must comply with all national and local codes, laws and regulations. Milbank reserves the right to make changes in specifications and features shown without notice or obligation.